


Controller

User Guide




- What's in the Box**
- Controller
 - Mini USB (use for firmware updates)
 - 3.5 mm cable (use to connect to module)
 - Power supply

Controller Compatibility




Vega

Wireless



Sol

Wireless*
Wired




Nano


Wireless*
Wired

*Wireless adapter required. (Sold separately)

Controller Display & Navigation




- 1 Wireless Strength
- 2 Module Name
- 3 Lunar Cycle Indicator
- 4 Current Mode
- 5 Active Timers
- 6 Current Intensities
- 7 Date and Time
- 8 Current Key Functions



Set the Wireless Connection

Vega
To connect the Controller with a Vega module, make sure the LED on the side of the Vega (next to power supply plug in) is red.

Press and hold the red button for approximately seven seconds. The light will alternate back and forth from red to green.



Wireless Module
To connect a Sol or Nano module with the wireless adapter, press the reset button using a paperclip or other object for approximately seven seconds to change the light from green to red.

up" throughout the day. Then, the colors "ramp down" in the reverse order during sunset to the lowest intensity again.

- From the Home screen, press MENU.
- Press SELECT to open the Timer Setup (Easy) menu option.
- Set the hour/minute/AM/PM for the sunrise and sunset and the hour/minute for ramp time.
- Press OK. The Color Settings window displays.
- Confirm or change the maximum and nite percentage values for each LED color. NOTE: The LED colors differ depending on the AI module you have connected to the controller.
- Press OK. You return to the main menu.
- After you confirm your settings in the Timer Setup (Easy) menu option, scroll down to the Timer Setup

(Manual) option. You will see the six individual timers you created in the easy setup mode.

Timer Setup (Manual)

You can individually set values for each timer using the Timer Setup (Manual) menu option after completing the Timer Setup (Easy) settings or you can move directly to the manual setup mode.

If you used the easy setup mode, you will see six individual timers generated from your settings. There are additional timers available, but you will notice that they are grayed out until you select them and set values. You can turn all timers on or off and you can modify them with your specific preferences. You can also add more timers, up to 30 total.

- From the Home screen, press

- MENU.
- Scroll down to the Timer Setup (Manual) menu option and press SELECT.
- For active timers, select your desired settings for time, color, level and ramp time. For inactive timers, use the right or left arrow to select Yes, and then change the settings.
- Press OK. The main menu displays your real-time light settings.

Weather Effects

Weather effects are disabled by default and it is up to you if you want to enable them. You can set several weather effects to mimic a natural habitat, which benefits your entire lighting system.

- From the Home screen, press MENU.

- Scroll down to the Weather Effects menu option and press SELECT.
- Enable the weather effects, then select your desired settings for chances, # per day, coverage, lightning and limit to.

Lunar Cycle

By default, the lunar cycle is disabled. Enable the lunar cycle function to decrease the intensity of the lights based on the current cycle of the moon. The lunar cycle approximates the eight phases of the moon throughout a month's time.

For the lunar cycle to work correctly, the date and time need to be correct. You should set your night-time intensity to what you want a full moon to look like.

- From the Home screen, press

- MENU.
- Scroll down to the Lunar Cycle menu option and press SELECT.
- Select Yes to enable the lunar cycle.
- Select the start and end times for the lunar cycle.
- Press OK.
- Return to the Home screen. When the lunar cycle is active during the start and end time you selected, the moon icon displays on the Home screen.

Test Run

The New Controller is equipped with two light test functions. At any time, you can complete a test run to cycle through your 24-hour settings in two minutes. Use this function to quickly see if your settings function as you expected.

- From the Home screen, press

To complete the wireless setup for the Vega:

- From the Home screen, press MENU.
- Scroll down to the Setup Lights menu option and press SELECT.
- Select Vega as the model and wireless as the connection.
- Press OK. The Wireless Setup window displays and the device searches for lights. A progress bar indicates the status.
- A message displays, indicating whether lights are detected. If all lights are found, press OK.
 - If you have multiple modules connected, you need to indicate what order the lights are in above the tank (on the next screen that displays). The lights are counted from the left. A module in the middle needs to be set as Left +1.

- Continue this process for all discovered lights and press OK.
- Return to the Home screen to see the signal strength of your wireless connection.

Change the Wireless Options

This menu is grayed out/unavailable before you establish the wireless connection. You can set the sweep direction to uniform, left-to-right or right-to-left. You can set the sweep speed to auto, or anywhere from 1-10.

- MENU.
- Scroll down to the Test Run menu option and press SELECT. The controller runs through the 24-cycle of your timers in 2 minutes.
- If the controller settings do not function as you expected, change your settings as needed.
- Press OK.

- right arrow key. Move to the next or previous color using the up or down arrow key.
- Press OK.

Screen Saver

You can enable the screen saver and set the length of inactive time before the screen saver displays. You can set it from 1-30 minutes.

- From the Home screen, press MENU.
- Scroll down to the More menu option and press SELECT.
- Scroll down to the Screen Saver menu option and press SELECT.
- Enable the screen saver.
- Select the length of inactive time before the controller goes into screen saver mode.
- Press OK.

Switch Modes

Use this menu option to switch back and forth between Auto and Manual modes. When you switch the controller to manual mode, the menu options change.

- To switch from Auto to Manual mode:**
- From the Home screen, press MENU.
 - Scroll down More menu option and press SELECT.
 - Scroll down to the Switch Modes menu option and press SELECT. A pop-up message asks if you want to switch to Manual mode.
 - Press OK.
 - The menu options reconfigure to display only the relevant options for operating the controller manually.

- To switch from manual to auto mode:**
- From the Home screen, press MENU.

Set the Clock

The clock must be set to the correct time and date for settings such as the lunar cycle to work properly.

- From the Home screen, press MENU.
- Scroll down to the More menu option and press SELECT.
- Scroll down to the Set Clock menu option and press SELECT.

- Set the correct hour, minutes, seconds and select AM or PM.
- Set the correct month, day and year.
- Set the Auto DST menu option to Yes if you want the controller to automatically adjust for daylight savings time or No if you do not want that setting.
- Press OK.

Key Sensitivity

The key sensitivity is automatically set to 03 on the New Controller. To make the keys less sensitive, requiring more pressure/a harder press when you push a key, set the key sensitivity to a higher number. To adjust the keys so they are more sensitive, requiring less pressure when you press a key, select a lower number.

- From the Home screen, press MENU.
- Scroll down to the More menu option and press SELECT.
- Scroll down to the Key Sensitivity menu option and press SELECT.
- Select a key sensitivity setting from 1-10.
- Press OK.

Firmware Update

When your controller is connected to a module, you are prompted whenever a firmware update is available and you need to update your software. When your controller is not connected, you can visit the support website to see when the latest firmware updates are available.

Note:
For best performance, make sure the controller is located near your lights to prevent signal interruption during firmware updates.

Factory Reset

- From the Home screen, press MENU.
- Scroll down to the More menu option and press SELECT.
- Scroll down to the Factory Reset menu option and press SELECT. A warning message displays to remind you that all of your custom settings for timers and effects will be erased if you proceed.
- Press OK.
- The controller restarts. The Setup Lights menu option displays so that you can customize your settings.

Videos
For videos on use and setup scan the QR code to visit our YouTube™ page



FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received including interference that may cause undesired operation. Any changes or modifications not expressly approved by C2 Development Inc. could void the user's authority to operate the wireless radio module, and/or the product that incorporates the wireless radio module.

Declaration of Conformity

We, the undersigned,
C2 Development, Inc.
127 S Bell Ave.
Ames, IA 50010 USA
Phone: 515-233-5105

certify and declare under our sole responsibility that the following equipment:

Product description / Intended use	Wireless lighting controller
EU / EFTA member states intended for use	EU: Austria, Belgium, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, The Netherlands, Poland, Portugal, Slovakia, Slovenia, Spain, Sweden, United Kingdom EFTA: Switzerland, Iceland, Liechtenstein, Norway
Manufacturer	C2 Development, Inc.
Brand	Aquaillumination (AI)
Type (Model reference that will appear on product/ CE label)	AI Wireless Controller

is tested to and conforms with the essential requirements for protection of health and the safety of the user and any other person and Electromagnetic Compatibility, as included in following standards:

Standard	Issue date
ETSI EN 301 489-1 V1.8.1 (2008-04)	12/1/12
ETSI EN 301 489-3 V1.4.1 (2002-08)	
IEC 60950-1:2008 – Information technology equipment – Safety – Part 1	

Set the Wired Connection

- From the Home screen, press MENU.
- Scroll down to the Setup Lights menu option and press SELECT.
- Select Sol Blue, Sol White or Nano as the model and Wired as the connection.
- Press OK.

Timer Setup (Easy)

If you need a simple day and night ramp or you are just starting out with the timers, this is the recommended option for setting up timers. The easy setup creates six individual timers in the manual setup screen. The method behind the sunrise/sunset ramp up method is to begin with the least intensity and "ramp

Coral Acclimation

By default, the coral acclimation setting is disabled. Enable the coral acclimation setting to introduce new corals to light gradually to prevent burning or bleaching. Set the reduction factor using 10% increments and select start and end dates for the acclimation period.

- From the Home screen, press MENU.
- Scroll down to the More menu option and press SELECT.
- Scroll down to the Coral Acclimation menu option and press SELECT.
- Set the reduction factor, start date and end date.
- Press OK.
- Your settings are reduced by the acclimation factor you selected. The lower intensity continues until midnight on the end date.

and is tested to and conforms with the essential radio test suites so that it effectively uses the frequency spectrum allocated to terrestrial/space radio communication and orbital resources so to as to avoid harmful interference, as included in following standards:

Standard	Issue date
ETSI EN 300 440-2 V1.4.1 (2101-08)	12/1/12

and therefore complies with the essential requirements and provisions of the Directive 1999/5/EC of the European Parliament and of the Council of March 9, 1999 on Radio equipment and Telecommunications Terminal Equipment and the mutual recognition of their conformity and with the provisions of Annex IV (Conformity Assessment procedure referred to in article 10).

The technical documentation as required by the Conformity Assessment procedure is kept at the following address:

TCF/TF reference nr.	C2 Development 2012304TCF
Drawn up in	Herndon, VA
Date	12/1/12


Name and position Chris Clough - President

