

D-D P1 Time Synchronisation

- When the power is first applied to the P1, the red LED flashes to indicate that time synchronisation is required.
- After the P1 has been successfully connected via the APP, the time from the APP will be synchronised with the P1- the red LED will be permanently lit, and the dosing plan will be performed according to the correct time.
- ***If there is a power outage, as soon as the power is resumed to the P1, the P1 will lose its synchronised time and assume the time is now 0:00 and start the dosing schedule accordingly. The P1 will have the red LED flashing to indicate it needs to connect to the APP again to synchronise the correct time to the P1.***